
one 5 pF capcitor can be used alternativly, C1 or C2 must be shorted in this case with solder, a piece of wire or a 0 0hm resistor



The advantages of using 4 x BPW34F(A) diodes are:
- x4 increased sensitivity towards ionizing radiation (x4 sensitive volume)

- less sensitive to disturbing electromagnetic interferences (due to lower signal amplification)

- less sensitive to stray light (due to the black plastic cases of the BPW34F(A) diodes)

- much less susceptible to the microphony effect / mechanical vibrations (due to lower signal amp.)

Following changes are need for the 4-diode variant using BPW34F(A) diodes:

D1 - D4 = BPW34F or BPW34FA, from Osram or Vishav

R3 = 10M

R4 = 1k

R5 = 100k

R8 = 0 (short with a wire)

C4 = 100n

C6 = 10p

C9 = not needed (DNP = do not populate)

All hardware & software source files plus detailed instructions on: www.github.com/ozel/DIY_particle_detector Details on the physics of the sensors & reference measurements: www.mdpi.com/1424-8220/19/19/4264 (www.doi.org/10.3390/s19194264)

MK1 via for coincidence sandwich

MK2 via for coincidence sandwich

MK3 via for coincidence sandwich

MK4 via for coincidence sandwich Suitable aluminium die-cast enclosures (besides your favourite candy tin box): Multicomp G102MF (Farnell nr. 1902552), fits precisely including edge mount screws http://uk.farnell.com/multicomp/g102mf/box-diecast-90x36x30mm/dp/1902552 Deltron 480-0010 (Farnell nr. 1774842), no mounting holes inside http://uk.farnell.com/deltron-enclosures/480-0010/box-diecast-ip68/dp/1774842





